



1.) Measure the width from stud wall to stud wall (*record the measurement*)

2.) Measure the depth from the front of the finished curb to the back stud wall - subtract 4" for HardCurb® (*record the measurement*)

3.) Measure the drain center from 1 stud wall to the center of the drain (*record the measurement*)

4.) Measure the drain center from a perpendicular stud wall (*record the measurement*)

A.) Future shower basin area

B.) Future curb area