



KBRS ShowerNiche™ Installation Guide

The following Installation Guide is intended to provide an easy to follow step by step process for installing a KBRS ShowerNiche™. When installing any KBRS tileable wet area substrate you should also consider the recommendations and standards established for wet area tile installations set forth by the Tile Council of North America, Inc. For any further assistance please contact KBRS Technical Services.

INSTALLATION INSTRUCTIONS:

1. Position ShowerNiche™ against a plumb and true wall stud so that the front edge of ShowerNiche™ extends out beyond the stud equal to the thickness of backerboard being installed. Securely attach ShowerNiche™ to the vertically framed wall stud using a minimum of two tile backerboard screws. *(For existing wall installations, attach ShowerNiche™ flush with existing wallboard).*
2. Apply a liberal amount of KBRS ShowerSeal® Polyurethane Sealant *(or equal)* to the outside of each screw head to fill any void. Tool sealant flush.
3. Measure and cut backerboard to fit snug around ShowerNiche™. Apply a bead of KBRS ShowerSeal® Polyurethane Sealant *(or equal)* around the outer perimeter of the ShowerNiche™ where the niche and backerboard meet *(the seams)*. Waterproof seams using an ANSI 118.10 compliant waterproofing.